


BLR



Table of Contents

Tavola	Page
BLR_parte 1	3



Machine: BLR

Assembly: BLR_parte 1



Pos	Code	Description	NOTE	Q.
1	BLR-001.120	Welding Frame 120		1
1	BLR-001.180	Welding Frame 180		0
2	BLR-002.120	Steel Roller 120		1
2	BLR-002.180	Steel Roller 180		1
2	BLRS-002.120	Steel Roller BLRS 120		1
2	BLRS-002.180	Steel Roller BLRS 180		1
3	BLR-003	Support tube		1
4	BLR-004	3-Point Bracket		5
5	BLR-005	Support leg		1
6	BLR-006	Pillow Block Bearing		2
7	BLR-007	Thread Plug		1
8	BLR-008	Pin Ø 19x100		1
9	BLR-009	R Pin		1
10	BLR-010	bolt M16x100		2
11	BLR-011	Pin		2
12	BLR-012	Bolt		2
13	BLR-013	bolt		8
14	BLR-014	Flate Washer		2
15	BLR-015	Spring Washer		2
16	BLR-016	Nut		2
17	BLR-017	Flate Washer		8
18	BLR-018	Spring Washer		8
19	BLR-019	Nut		8
20	BLR-020	Safe Pin		1