

Macchina


TT



Sezione

1

TT



SerNo	PartNo	Description	Quantity
1	T1050-01	Coupler	1
2	T1050-02	Screw Bolt M10x65	2
3	T1050-03	Washer M10	4
4	T1050-04	Locknut M10	2
5	T1050-05	Front-axle beam	1
6	T1050-06	Mesh	1
7	T1050-07	Screw Bolt M12x35	8
8	T1050-08	Screw Bolt M12x80	2
9	T1050-09	Front bracket	1

10	T1050-10	Upper arm & Lower arm	4
11	T1050-11	Back-axle beam	1
12	T1050-12	Wheel 22x12-8	4
13	T1050-13	Cross member	1
14	T1050-14	Rocker arm	2
15	T1050-15	Stud axle	4
16	T1050-16	Screw Bolt M12x65	8
17	T1050-17	Screw Bolt M24x154	2
18	T1050-18	Washer M24	4
19	T1050-19	Locknut M24	2
20	T1050-20	Back bracket	1
21	T1050-21	Washer M12	20
22	T1050-22	Locknut M12	10